

1. Multiply these figures by the square root of the required area to obtain dimensions.
2. Lay out triangle ACT.
3. Lay out the luff curve by plotting the height and offset from line AT of each forward batten end.
4. Lay out the leech. Starting at the bottom, strike an arc representing the length of the leech section from point C, and an arc representing the batten length from point B; and the intersection point will be the end of the batten at point D. Repeat for all the higher batten positions and the yard.

Generic "Fantail" Sail Planform